Exploded

E3021 ABDUCTOR

please note :prats didn't demolitionde part and fast eners not listde on the introduction





Number	Name	Quantity
D16	Self lock nut M10	4
D12	Flat washer ϕ10	4
D11	Cup head inner hex screw M10*75	4
D2	Cup head inner hex screw M8*80	4
D1	Cup head inner hex screw M8*35	2

Number	Name	Quantity
C35	Shoulder screw ϕ10*20	2
C27	Socket cap inner hex M10*65	4
C26	Flat washer ϕ10	4
C23	Self lock net M12	4
C19	Socket cap inner hex M12*40	4
C18	Bearing basement FL205铁	2
C16	Bearing basement PA205铁	2
B	Weight stack set	1
A32	Flat washer ϕ8	14
A31	Cup head inner hex screw M8*16	8
A30	Gasket DQ003	18
A29	Screw cap ϕ12	18
A28	Spring screw ϕ12	18
A27	Outer hex screw M12*35	10
A12	Back shroud HB14	1
A11	Front shroud HB18	16
A10	Cup head inner hex screw M6*15	8
A9	Cup head cross tapping screw ST5*16	1
A2	Head cover S907	1
A1	Head cover S908	1
DZ223	Leg pressing set DZ223	2
DZ224	Upholstery DZ224	1
DZ201	Backrest DZ201	1
12	Handle set	1
11	Selection sets	1
10	Strengthen set	2
08	Rod fix panel	1
06	Cam sets	1
05	Right working arm	1
04	Left working arm	1
02	Door frame	1
01	Main frame	1